

Tools Required



Floor Prep



Measuring Cup



Wet & Dry Vac



Floor Finish Dispensing Valve



First Impressions Floor Coating Or Ultra Reflections Floor Finish



Mop & Bucket



Wet Floor Sign



Microfiber Dust Mop



Back-pack Vacuum



16 oz. bottle Zing CPC



175 Zinger Low Speed Machine w/weights



Black Strip



18" Hard Surface Floor Tool



1500 Zinger High Speed Burnisher



Medium Grade Hair Pad



Microfiber Flat Mop Finish Applicator



Carpet Fan



Zing Dust Control



Flat Mop Holder with Handle



UV Marker & Light



ZING FLOOR PREP

Hard Floor Installation & Repair Task Schedule



PURPOSE

Install on top of any floor system without stripping. Also use to repair and recondition large floor areas.

Hard Floor - Installation & Repair

Task Schedule

Key Functions



Vacuum is preferred, dust mop is second choice.



Add weights to side to side machine for best results.



Mix **Zing Floor Prep** 8 oz. per gallon with *cold water*.




Black Strip Pad

Use standard **Black Strip Pad**.
Work machine in both directions.



After rinsing, **CPC** high speed burnish floor while damp.



First to last coat Make a line
last coat Cross to make a "T"

To monitor floor finish wear, place "**T**" marks using a **Permanent UV Marker** on the last two coats of floor finish applied.

Procedures

Place Wet Floor Signs

Vacuum or Dust Mop

Pre-spray edges with
un-diluted **Zing Floor Prep**

Mix **Zing Floor Prep** 8 oz.
per gallon with cold water.
Mop on floor and let dwell
5 min. * **Keep Floor Wet** *

Scrub in both directions

Pick up solution and rinse
with 2 oz. **Zing Floor Prep**
per gallon with cold water.

High speed burnish with **Zing
CPC** while floor is damp.

Vacuum or dust mop once
more prior to applying finish.

Pour finish on floor in straight
lines using the **Floor Finish
Dispensing Valve**. Spread
with Microfiber Flat Mop.
4 coats maximum in 24 hour
period.